



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
  2. DIMENSIONS SHOWN IN INCHES AND (mm).
  3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
  4. REQUIRES 99 STRIKE FOR BACKSET.

HDG. \_\_\_\_\_ DR. \_\_\_\_\_

**RESPONSIBILITY**  
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE  
 METAL DOOR  
 O3P/O3PN  
 CYLINDER PULL TRIM

**DETEx**  
CORPORATION

DO NOT SCALE DRAWING

DATE 11/16/07	TEMPLATE NUMBER T1099
---------------	-----------------------