


- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
  2. DIMENSIONS SHOWN IN INCHES AND (mm).
  3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
  4. SEE T2002 FOR DEVICE SIDE PREP.

RESPONSIBILITY		H.D.G. _____ DR. _____			
Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.					
TEMPLATE STEEL/ALUMINUM DOOR 08, 09 & 14 EU x DM/DMT/DMU WIDE LEVER TRIM-ELECT. LOCKING BP-9 MOUNTING PLATE				DO NOT SCALE DRAWING	
		DATE	7-23-10	TEMPLATE NUMBER	T1170