EAX-2500S with Strobe / ACD x 1S – 5 FXG

Point to Point Wiring Diagram 90-800 SW2B 120AC Negg 2nd switch sold separately MS-1039S ■ Door Frame White Black N.O.


EAX-2500S

Part Description: Diagram EAX-2500S with Strobe ACD 5 FXG

DWG NO: 104858

Date: 2- 25-15

302 Detex Drive New Braunfels, Texas 800-7293839 www.detex.com



Theory of Operations

- 1. The EAX-2500S has a key stop installed, the key can only be removed in the armed position.
- 2. With the door closed turn the key counter clockwise from about 2:00 o'clock to 12:00 o'clock or until you get two red flashes followed by a solid green LED for 15s, remove the key. When the green LED turns off the EAX-2500S will sound 3 chirps indicating that it is armed.
- 3. If the door is opened without turning the EAX2500S off the EAX2500S will go into alarm, this in turn will cause the SW2B to activate.
- 4. The alarm can only be silenced with the key.
- 5. If the screws are removed when the EAX2500S is armed it will also go into alarm.

