

Electric Unlock (EU) HOW TO ORDER


ELECTRIC TRIM

*EU = for use with wide stile rim and SVR exit devices

EUxDM = for use with mortise exit devices

EU2W = for use with narrow stile rim and SVR exit devices

EUV = for use with 70/80 Series CVR



Examples: 10EU (includes 10 Series, 08 trim function, D type trim, S lever, Fail Secure, 626 finish, RHR)
 10EU x FSA (includes 10 Series, 09 trim function, D type trim, S lever, Fail Safe, 626 finish, RHR)
 30EU x FSA x DMT x 605 x LHR (includes 30 Series, 09 trim function, DM type trim, T lever, Fail Safe, 605 finish, LHR)
 V40EU2W x MC65 (includes V40 Series, 08 trim function, D type trim, S lever, Fail Secure, MC65, 626 finish, RHR)

NOTE: * = default
 ** = for mortise only

